



<http://www.autocatalogues.com>

Модели представленные в каталоге автозапчастей Isuzu (Исудзу):

Isuzu Vehicle AUV

50663 TBR(INDONESIA) 1991-1996 ISUZU Vehicle AUV
50823 TBR(INDONESIA) 2000-2004 ISUZU Vehicle AUV
50909 TBR-LHD 2001- ISUZU Vehicle AUV
50919 TBR (GM-INDONESIA) 2002- ISUZU Vehicle AUV
51128 TBR-LHD 2007- ISUZU Vehicle AUV
51134 TBR-PICKUP INDONESIA 2007- ISUZU Vehicle AUV
51135 TBR-WAGON(INDONESIA) 2007- ISUZU Vehicle AUV

Isuzu Vehicle Pickup

50651 TFR/TFS-RHD 1993-1996 ISUZU Vehicle Pickup
50652 TFR/TFS-LHD 1993-1996 ISUZU Vehicle Pickup
50725 TFR/TFS-RHD 1997-1998 ISUZU Vehicle Pickup
50726 TFR/TFS-LHD 1997-1998 ISUZU Vehicle Pickup
50727 TFR/TFS(EUROPE)-LHD 1997-1998 ISUZU Vehicle Pickup
50800 TFR/TFS-RHD 1999-2003 ISUZU Vehicle Pickup
50801 TFR/TFS-LHD 1999-2003 ISUZU Vehicle Pickup
50802 TFR/TFS(EUROPE)-LHD 1999-2003 ISUZU Vehicle Pickup
50890 TFR/S(THAILAND) 2001-2002 ISUZU Vehicle Pickup
50920 TFR/TFS(EUROPE)-RHD 2002-2003 ISUZU Vehicle Pickup
50931 TFR/TFS(THAILAND) 2003-2011 ISUZU Vehicle Pickup
50936 TFR/TFS(AUSTRALIA) 2003- ISUZU Vehicle Pickup
50958 TFR/TFS THAI-RUNG 2003- ISUZU Vehicle Pickup
50964 TFR/TFS-LHD 2004-2011 ISUZU Vehicle Pickup
50965 TFR/TFS-RHD 2004-2008 ISUZU Vehicle Pickup
50966 TFR/TFS(EUROPE)-LHD 2004- ISUZU Vehicle Pickup
50967 TFR/TFS(EUROPE)-RHD 2004- ISUZU Vehicle Pickup
50982 TFR/S(CHEVROLET)THAI 2005- ISUZU Vehicle Pickup
51100 TFR/S GM MIDDLE EAST 2007- ISUZU Vehicle Pickup
51171 TFR/TFS CHEV HOLDEN 2008- ISUZU Vehicle Pickup
51194 TFR/TFS-RHD 2009-2011 ISUZU Vehicle Pickup
51277 TFR/TFS MIDDLE EAST 2004- ISUZU Vehicle Pickup
51373 TFR/TFS(THAILAND) 2012- ISUZU Vehicle Pickup
51374 TFR/TFS(EUROPE)-LHD 2012- ISUZU Vehicle Pickup
51375 TFR/TFS(EUROPE)-RHD 2012- ISUZU Vehicle Pickup
51408 TFR/TFS MIDDLE EAST 2012- ISUZU Vehicle Pickup
51411 TFR/TFS-LHD 2012- ISUZU Vehicle Pickup
51412 TFR/TFS-RHD 2012- ISUZU Vehicle Pickup
51421 TFR/TFS(MALAYSIA) 2013- ISUZU Vehicle Pickup
51472 TFR/TFS MIDDLE EAST 2013- ISUZU Vehicle Pickup
51473 TFR/TFS-LHD 2013- ISUZU Vehicle Pickup
51474 TFR/TFS-RHD 2013- ISUZU Vehicle Pickup
51476 TFR/TFS(EUROPE)-LHD 2013- ISUZU Vehicle Pickup
51477 TFR/TFS(EUROPE)-RHD 2013- ISUZU Vehicle Pickup
51485 TFR SHORT(THAI) 2013- ISUZU Vehicle Pickup
51491 TFR/TFS(THAILAND) 2014- ISUZU Vehicle Pickup



Isuzu Vehicle SUV

- 50658 UBS-RHD 1992-1997 ISUZU Vehicle SUV
- 50659 UBS-LHD 1992-1997 ISUZU Vehicle SUV
- 50685 WFR-RHD 1994-1995 ISUZU Vehicle SUV
- 50686 WFR-LHD 1994-1995 ISUZU Vehicle SUV
- 50688 UC-LHD 1993-1997 ISUZU Vehicle SUV
- 50754 UES(4DOOR)-LHD 1998- ISUZU Vehicle SUV
- 50757 UBS-RHD 1998-2002 ISUZU Vehicle SUV
- 50775 UBS-LHD 1998- ISUZU Vehicle SUV
- 50803 UBS(TAIWAN)-LHD 1998- ISUZU Vehicle SUV
- 50807 UES(AUSTRALIA) 1999- ISUZU Vehicle SUV
- 50892 UCS(THAILAND) 2001-2004 ISUZU Vehicle SUV
- 51027 UCR/UCS(THAILAND) 2005- ISUZU Vehicle SUV
- 51032 UCR/UCS-LHD 2005- ISUZU Vehicle SUV
- 51488 UCR/UCS(THAILAND) 2014- ISUZU Vehicle SUV
- 51489 UCR/UCS-RHD 2014- ISUZU Vehicle SUV
- 51506 UCR RHD (INDIA) 2014- ISUZU Vehicle SUV

Isuzu Vehicle Buses

- 10648 CHR/CJR/CQR 1990-1999 ISUZU Vehicle Buses
- "10650 MT111 112 1991-2004" ISUZU Vehicle Buses
- 10662 MT(THAI) 1991-1994 ISUZU Vehicle Buses
- 10663 MR 1991-1995 ISUZU Vehicle Buses
- "10676 LT 111 112 132 133 1991-" ISUZU Vehicle Buses
- 10695 LV233(THAI) 1998- ISUZU Vehicle Buses
- 10772 LV280(THAI) 1997- ISUZU Vehicle Buses
- 10794 LT(TAIWAN) 1998-2006 ISUZU Vehicle Buses
- 10818 LV123/150/423-RHD 2001- ISUZU Vehicle Buses
- 10824 MR-LHD 2000- ISUZU Vehicle Buses
- 10852 LV123/150-LHD 2001- ISUZU Vehicle Buses
- 10853 MV123(RHD) 2001- ISUZU Vehicle Buses
- 10857 MV118 1995- ISUZU Vehicle Buses
- 10885 LV423(THAI)BMTA 2001- ISUZU Vehicle Buses
- 10892 LT134-RHD EXC.EURO4 2001- ISUZU Vehicle Buses
- 10948 LV123/423-LHD 2004- ISUZU Vehicle Buses
- 10969 MT133-RHD 2005- ISUZU Vehicle Buses
- 11031 LT134-RHD EURO4 2007- ISUZU Vehicle Buses
- 11032 LT134(LHD) EURO4 2007- ISUZU Vehicle Buses
- 11049 LV434(RHD) EURO4 2007- ISUZU Vehicle Buses
- 11100 LV434(LHD) EURO4 2007- ISUZU Vehicle Buses
- 11206 LT134(LHD) EURO2/3 2009- ISUZU Vehicle Buses
- 11207 LT134(RHD) EURO2/5 2009- ISUZU Vehicle Buses
- 11208 LV434(LHD) EURO3 2009- ISUZU Vehicle Buses
- 11209 LV434(RHD) EURO3/5 2009- ISUZU Vehicle Buses
- 11523 LV152/452(LHD) EURO4 2013- ISUZU Vehicle Buses
- 11562 LT434-RHD EURO5 2014- ISUZU Vehicle Buses



Isuzu Vehicle Trucks

10585 CXH-RHD 1986-1995 ISUZU Vehicle Trucks
10624 FSR-RHD 1992-1995 ISUZU Vehicle Trucks
10625 FSR-LHD 1993-1995 ISUZU Vehicle Trucks
10626 FTR-RHD 1992-1995 ISUZU Vehicle Trucks
10627 FTR-LHD 1992-1995 ISUZU Vehicle Trucks
10630 FVR-RHD 1992-1995 ISUZU Vehicle Trucks
10631 FVR-LHD 1992-1995 ISUZU Vehicle Trucks
10632 FVM-RHD 1992-1995 ISUZU Vehicle Trucks
10633 FVZ-RHD 1992-1995 ISUZU Vehicle Trucks
10634 FSS/FTS-RHD 1992-1995 ISUZU Vehicle Trucks
10635 FSS/FTS-LHD 1992-1996 ISUZU Vehicle Trucks
10653 EXZ 1990-1995 ISUZU Vehicle Trucks
10658 EXR-RHD 1990-1995 ISUZU Vehicle Trucks
10660 CXZ-RHD 1990-1995 ISUZU Vehicle Trucks
10661 CVR 1990-1995 ISUZU Vehicle Trucks
10669 CXM/CXZ-LHD 1990-1995 ISUZU Vehicle Trucks
10672 EXR-LHD 1990-1995 ISUZU Vehicle Trucks
10698 FRR(RHD)EXC. EURO3 1996-2006 ISUZU Vehicle Trucks
10699 FRR(LHD) EXC.EURO4 1996- ISUZU Vehicle Trucks
"10700 FSR32 33(RHD) 1996-" ISUZU Vehicle Trucks
10701 FSR(LHD) EXC.EURO4 1996- ISUZU Vehicle Trucks
10702 FTR(RHD)EXC. EURO3 1996-2006 ISUZU Vehicle Trucks
10703 FTR(LHD) EXC.EURO4 1996- ISUZU Vehicle Trucks
10704 FVR/GVR-RHD 1996- ISUZU Vehicle Trucks
10705 FVR(LHD) EXC.EURO4 1996- ISUZU Vehicle Trucks
10706 FVM-RHD 1996- ISUZU Vehicle Trucks
10707 FVZ-RHD 1996- ISUZU Vehicle Trucks
10716 FSS/FTS-RHD 1996- ISUZU Vehicle Trucks
10717 FSS/FTS-LHD 1996- ISUZU Vehicle Trucks
10720 CXZ-RHD 1996-2000 ISUZU Vehicle Trucks
10721 CXM/CXZ-LHD 1996-2000 ISUZU Vehicle Trucks
10722 CXH-RHD 1996-2000 ISUZU Vehicle Trucks
10723 CVR-LHD 1996-2000 ISUZU Vehicle Trucks
10724 EXR-RHD 1996-2000 ISUZU Vehicle Trucks
10725 EXR-LHD F/T 200L 1996-2000 ISUZU Vehicle Trucks
"10726 EXZ F/T 200L 300L 1996-2000" ISUZU Vehicle Trucks
10739 FSR-LHD(BUS CHASSIS) 1996- ISUZU Vehicle Trucks
10752 FTR(IDN)WB3600/4200 1997-2004 ISUZU Vehicle Trucks
10753 FVM(INDONESIA)WB5300 1997-2004 ISUZU Vehicle Trucks
10754 FXZ(INDONESIA) 1997-2004 ISUZU Vehicle Trucks
10775 FRR/FVR(TAIWAN) 1998-2007 ISUZU Vehicle Trucks
10780 FVM(THAI) 2001-2003 ISUZU Vehicle Trucks
10781 FTR(THAI) 2000-2003 ISUZU Vehicle Trucks
10796 EXZ-LHD F/T 400L 1999-2000 ISUZU Vehicle Trucks
10805 EXY-RHD 2000- ISUZU Vehicle Trucks
10806 EXZ-RHD F/T 400L 1999-2000 ISUZU Vehicle Trucks
10807 EXR-LHD F/T 400L 1999-2000 ISUZU Vehicle Trucks
10808 FRR-G/FSR/FTR TAIWAN 1999-2006 ISUZU Vehicle Trucks
10819 CXZ-RHD(SINGAPORE) 2000- ISUZU Vehicle Trucks
10820 CXZ-LHD(CHINA) 2000-2003 ISUZU Vehicle Trucks
10826 FRR/FSR/FRD(AUST) 2000- ISUZU Vehicle Trucks



10827 FTR(AUSTRALIA) 2000- ISUZU Vehicle Trucks
10828 FV/GV(AUSTRAL)L.SUS 2000- ISUZU Vehicle Trucks
10829 FV/GV(AUSTRAL)A.SUS 2000- ISUZU Vehicle Trucks
10831 FSS/FTS(AUSTRALIA) 2000- ISUZU Vehicle Trucks
10832 FSS(MALAYSIA)A/T 2001- ISUZU Vehicle Trucks
10834 FVM/FVZ-LHD 2000- ISUZU Vehicle Trucks
10854 FVR-LHD(BUS CHASSIS) 2001- ISUZU Vehicle Trucks
10860 CVR-LHD 2001- ISUZU Vehicle Trucks
10862 EXR-LHD F/T400(+400) 2001- ISUZU Vehicle Trucks
10863 EXR-RHD F/T 200+200L 2001- ISUZU Vehicle Trucks
10864 EXR-LHD F/T 200+200L 2001- ISUZU Vehicle Trucks
"10865 EXD-RHD F/T 400 200L 2001-" ISUZU Vehicle Trucks
10866 EXD-LHD F/T 400L 2001- ISUZU Vehicle Trucks
10867 EXR-RHD F/T 400L 2001- ISUZU Vehicle Trucks
10868 EXR-LHD F/T 400L 2001- ISUZU Vehicle Trucks
10869 CXY51-RHD(AUSTRALIA) 2001- ISUZU Vehicle Trucks
10870 CXZ51-RHD(AUSTRALIA) 2001- ISUZU Vehicle Trucks
10871 EXZ-RHD F/T400(+400) 2001- ISUZU Vehicle Trucks
10872 EXZ-LHD F/T400(+400) 2001- ISUZU Vehicle Trucks
10873 CXM-LHD 2001- ISUZU Vehicle Trucks
10874 CXZ-RHD 2001-2002 ISUZU Vehicle Trucks
10875 CXZ-LHD 2001- ISUZU Vehicle Trucks
10876 EXZ-RHD F/T 200+200L 2001- ISUZU Vehicle Trucks
10877 EXZ-LHD F/T 200+200L 2001- ISUZU Vehicle Trucks
10878 EXZ-RHD F/T 400L 2001- ISUZU Vehicle Trucks
10879 EXZ-LHD F/T 400L 2001- ISUZU Vehicle Trucks
10880 CXZ-RHD 10P TWN VERT 2001-2002 ISUZU Vehicle Trucks
10882 CXH-RHD 2001-2002 ISUZU Vehicle Trucks
10883 CXH-LHD 2001- ISUZU Vehicle Trucks
10889 FRR34(RHD) 2001- ISUZU Vehicle Trucks
10890 FSR34(RHD) 2001- ISUZU Vehicle Trucks
10891 FTR34(RHD) 2001- ISUZU Vehicle Trucks
10893 FVR(HONG KONG) 1996- ISUZU Vehicle Trucks
10896 FTR BUS CHASSIS LHD 1999- ISUZU Vehicle Trucks
10899 GXZ(THAI) 2002-2003 ISUZU Vehicle Trucks
10907 FXZ(THAI) 2003-2003 ISUZU Vehicle Trucks
10908 FVZ(THAI) 2003-2003 ISUZU Vehicle Trucks
10910 CXJ-RHD 2003- ISUZU Vehicle Trucks
10929 CXZ-RHD 2003- ISUZU Vehicle Trucks
10930 CXH-RHD 2003- ISUZU Vehicle Trucks
10935 FTR(INDONESIA)WB4600 2004-2006 ISUZU Vehicle Trucks
10936 GTR(INDONESIA) 2004-2006 ISUZU Vehicle Trucks
10937 FVM(INDONESIA)WB6300 2004-2006 ISUZU Vehicle Trucks
10942 FTR(THAI)EURO2 2004-2008 ISUZU Vehicle Trucks
10943 FVM(THAI)EURO2 2004-2008 ISUZU Vehicle Trucks
10944 FVZ(THAI)EURO2 2004-2008 ISUZU Vehicle Trucks
10945 GXZ(THAI)EURO2 2004-2008 ISUZU Vehicle Trucks
10946 FXZ(THAI)EURO2 2004-2008 ISUZU Vehicle Trucks
10949 CXZ(CHINA) 2005- ISUZU Vehicle Trucks
10950 EXR-LHD WEDGE BRAKE 2006-2009 ISUZU Vehicle Trucks
10953 CXH/CYH(NEW ZEALAND) 2004- ISUZU Vehicle Trucks
10954 CXZ/CYZ(NEW ZEALAND) 2004- ISUZU Vehicle Trucks



10955 EXZ(NEW ZEALAND) 2004- ISUZU Vehicle Trucks
10956 EXY(NEW ZEALAND) 2004- ISUZU Vehicle Trucks
10964 EXZ-LHD WEDGE BRAKE 2006- ISUZU Vehicle Trucks
11006 CYJ(NEW ZEALAND) 2005- ISUZU Vehicle Trucks
11010 CYH(LHD)W/2STEPS 2006- ISUZU Vehicle Trucks
11013 CXZ-LHD(WEDGE BRAKE) 2005- ISUZU Vehicle Trucks
11020 CXZ(AUSTRALIA) 2006- ISUZU Vehicle Trucks
11021 CXY(AUSTRALIA) 2006- ISUZU Vehicle Trucks
11022 CYZ-RHD 2006- ISUZU Vehicle Trucks
11023 CYZ(LHD)W/2STEPS 2006- ISUZU Vehicle Trucks
11024 EXD(AUSTRALIA) 2006- ISUZU Vehicle Trucks
11027 FRR(RHD) EURO4 2007- ISUZU Vehicle Trucks
11028 FSR(RHD) EURO4 2007- ISUZU Vehicle Trucks
11029 FTR(RHD) EURO4 2007- ISUZU Vehicle Trucks
11030 FVR(RHD) EURO4 2007- ISUZU Vehicle Trucks
11035 CYH(RHD)EURO4 2007- ISUZU Vehicle Trucks
11036 CYZ(RHD) EURO4 2007- ISUZU Vehicle Trucks
11037 EXR(RHD)EURO4 2007- ISUZU Vehicle Trucks
11038 EXD(RHD)EURO4 2007- ISUZU Vehicle Trucks
11039 EXZ(RHD)EURO4 2007- ISUZU Vehicle Trucks
11040 FRR(LHD) EURO4 2007- ISUZU Vehicle Trucks
11041 FSR(LHD) EURO4 2007- ISUZU Vehicle Trucks
11042 FTR(LHD) EURO4 2007- ISUZU Vehicle Trucks
11045 CYM(LHD) 2007- ISUZU Vehicle Trucks
11046 CYZ(LHD) EURO4 2007- ISUZU Vehicle Trucks
11047 EXR(LHD)EURO4W/2STEP 2007- ISUZU Vehicle Trucks
11048 EXZ(LHD)EURO4W/2STEP 2007- ISUZU Vehicle Trucks
11101 FRR-R EU2/4EXC.SPACE 2008- ISUZU Vehicle Trucks
11102 FRR-R S-CAB EURO2/4 2008- ISUZU Vehicle Trucks
11103 FSR-R EU2/4EXC.SPACE 2008- ISUZU Vehicle Trucks
11104 FTR-RHD EURO2/4 2008- ISUZU Vehicle Trucks
11105 FVM(RHD) 2008- ISUZU Vehicle Trucks
11106 FVR/GVR-RHD EURO2/4 2008- ISUZU Vehicle Trucks
11107 FVZ(RHD) 2008- ISUZU Vehicle Trucks
11109 CYH(NZ)JAPAN02/04 2008- ISUZU Vehicle Trucks
11110 CYJ(NZ)JAPAN02/04 2008- ISUZU Vehicle Trucks
11111 CYZ(NZ)JAPAN02/04 2008- ISUZU Vehicle Trucks
11112 CXZ/CYZ(R)JNLT05/EU5 2008- ISUZU Vehicle Trucks
11113 CXY(AUST)JNLT05/EU5 2008- ISUZU Vehicle Trucks
11114 EXD(AUST)JNLT05 2008- ISUZU Vehicle Trucks
11115 EXZ(NZ)JAPAN02/04 2008- ISUZU Vehicle Trucks
11116 EXY(AUST)JNLT05 2008- ISUZU Vehicle Trucks
11117 EXY(RHD)HYD-RETARDER 2008- ISUZU Vehicle Trucks
11118 EXY(NZ)JAPAN02/04 2008- ISUZU Vehicle Trucks
11120 FRR(LHD)EXC.SPACECAB 2008- ISUZU Vehicle Trucks
11121 FRR(LHD) SPACECAB 2008- ISUZU Vehicle Trucks
11122 FRR(THAI) 2008- ISUZU Vehicle Trucks
11123 FSR(LHD) 2008- ISUZU Vehicle Trucks
11124 FSS(RHD)EURO2/4 2008- ISUZU Vehicle Trucks
11125 FTR(THAI)EURO3 2008- ISUZU Vehicle Trucks
11126 FTR(INDONESIA)6HH1 2007- ISUZU Vehicle Trucks
11127 FTR(LHD) 2008- ISUZU Vehicle Trucks



11128 FTS(RHD)EURO2/4 2008- ISUZU Vehicle Trucks
11129 FVM(THAI)EURO3 2008- ISUZU Vehicle Trucks
11130 FVZ(THAI)EURO3 2008- ISUZU Vehicle Trucks
11131 FVM(INDONESIA)6SD1 2007- ISUZU Vehicle Trucks
11132 FVR/GVR(LHD) 2008- ISUZU Vehicle Trucks
11133 GVR(THAI)EURO3 2008- ISUZU Vehicle Trucks
11136 FXZ/GXZ(THAI)EURO3 2008- ISUZU Vehicle Trucks
11137 FRR-LHD(EU)SPACE EU4 2009- ISUZU Vehicle Trucks
11138 FRR-RHD(EU)SPACE EU4 2009- ISUZU Vehicle Trucks
11139 FSR-R(EU)EU4 EXC.SPA 2009- ISUZU Vehicle Trucks
11140 FSR-RHD(EU)SPACE EU4 2009- ISUZU Vehicle Trucks
11141 FVR-LHD(EUROPE)EURO4 2009- ISUZU Vehicle Trucks
11142 FVR-RHD(EUROPE)EURO4 2009- ISUZU Vehicle Trucks
11143 FXR/GXR EXC.EURO5 2008- ISUZU Vehicle Trucks
11144 FXM EXC.EURO5 2008- ISUZU Vehicle Trucks
11145 FXZ EXC.EURO5 2008- ISUZU Vehicle Trucks
11146 FSS(LHD) 2008- ISUZU Vehicle Trucks
11149 EXY(SOUTH AFRICA) 2008- ISUZU Vehicle Trucks
11150 FSR-LHD(EU)SPACE EU4 2009- ISUZU Vehicle Trucks
11151 FTS(LHD) 2008- ISUZU Vehicle Trucks
11152 FVM(LHD) 2008- ISUZU Vehicle Trucks
11153 FVZ(LHD)EURO2/3 2008- ISUZU Vehicle Trucks
11160 FRR SCAB S.AFRICA 2009- ISUZU Vehicle Trucks
11161 FSR(SOUTH AFRICA) 2009- ISUZU Vehicle Trucks
11162 FRREXC.SCAB S.AFRICA 2009- ISUZU Vehicle Trucks
11165 FTR SOUTH AFRICA 2009- ISUZU Vehicle Trucks
11166 FTS(SOUTH AFRICA) 2009- ISUZU Vehicle Trucks
11167 FVR(SOUTH AFRICA) 2009- ISUZU Vehicle Trucks
11168 FVM(SOUTH AFRICA) 2009- ISUZU Vehicle Trucks
11169 FVZ SOUTH AFRICA 2009- ISUZU Vehicle Trucks
11194 FTR CNG(THAILAND) 2009- ISUZU Vehicle Trucks
11195 GVR CNG(THAILAND) 2009- ISUZU Vehicle Trucks
11196 FXR/GXR SOUTH AFRICA 2010- ISUZU Vehicle Trucks
11197 FXZ SOUTH AFRICA 2010- ISUZU Vehicle Trucks
11198 CYH(NZ)EURO4/JNLT05 2009- ISUZU Vehicle Trucks
11199 CYZ(NZ)EURO4 2009- ISUZU Vehicle Trucks
11200 CYJ(NZ)EURO4/JNLT05 2009- ISUZU Vehicle Trucks
11201 EXY(NZ)EURO4 2009- ISUZU Vehicle Trucks
11227 FSR(CNG)AUSTRALIA 2009- ISUZU Vehicle Trucks
11230 FRR-LHD(EU)SPACE EU5 2010- ISUZU Vehicle Trucks
11231 FSR-LHD(EU)SPACE EU5 2010- ISUZU Vehicle Trucks
11232 FRR-R EU5 EXC.SPACE 2009- ISUZU Vehicle Trucks
11233 FSR-R EU5 EXC.SPACE 2009- ISUZU Vehicle Trucks
11234 FTR-RHD EURO5 2009- ISUZU Vehicle Trucks
11235 FVR-RHD EURO5 2009- ISUZU Vehicle Trucks
11236 FRR-RHD(EU)SPACE EU5 2010- ISUZU Vehicle Trucks
11237 FSR-R(EU)EU5 EXC.SPA 2010- ISUZU Vehicle Trucks
11238 FSR-RHD(EU)SPACE EU5 2010- ISUZU Vehicle Trucks
11239 FVR-LHD(EUROPE)EURO5 2010- ISUZU Vehicle Trucks
11240 FVR-RHD(EUROPE)EURO5 2010- ISUZU Vehicle Trucks
11271 CYH(L)EU2/3/4W/3STEP 2010- ISUZU Vehicle Trucks
11272 CYZ(L)EU2/3/4W/3STEP 2010- ISUZU Vehicle Trucks



11273 EXR(L)EU2/3/4W/3STEP 2010- ISUZU Vehicle Trucks
11274 EXZ(L)EU2/3/4W/3STEP 2010- ISUZU Vehicle Trucks
11288 FTS(THAI) 2009- ISUZU Vehicle Trucks
11289 CYH(RHD)EURO5 2010- ISUZU Vehicle Trucks
11290 CYZ(RHD)EURO5 2010- ISUZU Vehicle Trucks
11292 EXR(RHD)EURO5 2010- ISUZU Vehicle Trucks
11293 EXD(RHD)EURO5 2010- ISUZU Vehicle Trucks
11294 EXZ(RHD)EURO5 2010- ISUZU Vehicle Trucks
11303 FRR(AUST/NZ)EU5 SPAC 2011- ISUZU Vehicle Trucks
11304 FVM(AUST/NZ)EURO5 2011- ISUZU Vehicle Trucks
11305 FVZ(AUST/NZ)EURO5 2011- ISUZU Vehicle Trucks
11306 FSS(AUST/NZ)EURO5 2011- ISUZU Vehicle Trucks
11307 FTS(AUST/NZ)EURO5 2011- ISUZU Vehicle Trucks
11308 FYH(RHD)EURO5 2010- ISUZU Vehicle Trucks
11309 FXZ(RHD)EURO5 2010- ISUZU Vehicle Trucks
11310 FRR(MIDEAST) 1996-2003 ISUZU Vehicle Trucks
11311 FTS(MIDEAST) 1998-2007 ISUZU Vehicle Trucks
11312 FVZ(MIDEAST) 2000-2010 ISUZU Vehicle Trucks
11313 FXR(RHD)EURO5 2010- ISUZU Vehicle Trucks
11314 FXR/GXR(AUST)EURO5 2011- ISUZU Vehicle Trucks
11316 FXM(AUST)EURO5 2011- ISUZU Vehicle Trucks
11317 FXZ(AUST)EURO5 2011- ISUZU Vehicle Trucks
11318 CYH(MIDEAST)W/2STEPS 2006- ISUZU Vehicle Trucks
11320 EXR(MIDEAST)W/2STEPS 2006- ISUZU Vehicle Trucks
11321 EXZ(MIDEAST)W/2STEPS 2006- ISUZU Vehicle Trucks
11322 CYH(MIDEAST)W/3STEPS 2010- ISUZU Vehicle Trucks
11323 CYZ(MIDEAST)W/3STEPS 2010- ISUZU Vehicle Trucks
11324 EXR(MIDEAST)W/3STEPS 2010- ISUZU Vehicle Trucks
11325 EXZ(MIDEAST)W/3STEPS 2010- ISUZU Vehicle Trucks
11326 FRR(AUST/NZ)E5 EXC.S 2011- ISUZU Vehicle Trucks
11327 FSR(AUST/NZ)EURO5 2011- ISUZU Vehicle Trucks
11328 FTR(AUST/NZ)EURO5 2011- ISUZU Vehicle Trucks
11329 FVR(AUST/NZ)EURO5 2011- ISUZU Vehicle Trucks
11330 CYZ(MIDEAST)W/2STEPS 2006- ISUZU Vehicle Trucks
11333 FRR(MIDEAST)6H ENG 2004- ISUZU Vehicle Trucks
11339 FSR(MIDEAST) 1996-2007 ISUZU Vehicle Trucks
11340 FTR(MIDEAST) 1996- ISUZU Vehicle Trucks
11350 FRR(MIDEAST)4H ENG 2008- ISUZU Vehicle Trucks
11351 FVM CNG(THAILAND) 2011- ISUZU Vehicle Trucks
11352 FVR(MIDEAST) 1996-2007 ISUZU Vehicle Trucks
11354 FYH(THAILAND)EURO3 2011- ISUZU Vehicle Trucks
11357 FSR(MALAYSIA)W/B5500 2004-2011 ISUZU Vehicle Trucks
11358 FTS(MALAYSIA) 2000- ISUZU Vehicle Trucks
11360 FTR(MALAYSIA)W/B6000 2002- ISUZU Vehicle Trucks
11362 FRR-R S-CAB EU4 DOC 2011- ISUZU Vehicle Trucks
11363 FORWARD800(MEXICO) 2011- ISUZU Vehicle Trucks
11364 FSR(MALAYSIA)W/B4200 1997-2011 ISUZU Vehicle Trucks
11365 FSS(MALAYSIA)M/T 2006- ISUZU Vehicle Trucks
11366 FTR(MALAYSIA)W/B4600 2004- ISUZU Vehicle Trucks
11367 FSR-R W/DOC EXC.SPA 2011- ISUZU Vehicle Trucks
11368 FTR(LHD)EURO4 W/DOC 2011- ISUZU Vehicle Trucks
11369 FVR(LHD)EURO4 W/DOC 2011- ISUZU Vehicle Trucks



11370 FVR(RHD)W/DOC EURO4 2011- ISUZU Vehicle Trucks
11390 FRR(INDONESIA) 2011- ISUZU Vehicle Trucks
11391 FVM(INDONESIA)6HK1 2011- ISUZU Vehicle Trucks
11392 FVR(INDONESIA) 2011- ISUZU Vehicle Trucks
11393 FVZ(INDONESIA) 2011- ISUZU Vehicle Trucks
11395 FRR(RHD)EURO1 2011- ISUZU Vehicle Trucks
11398 FSR(LHD)EURO1 2011- ISUZU Vehicle Trucks
11399 FSR(RHD)EURO1 2011- ISUZU Vehicle Trucks
11401 FSS(RHD)EURO1 2012- ISUZU Vehicle Trucks
11405 FTS(RHD)EURO1 2012- ISUZU Vehicle Trucks
11408 FVR(LHD)EURO1 2011- ISUZU Vehicle Trucks
11409 FVR(RHD)EURO1 2011- ISUZU Vehicle Trucks
11412 FORWARD1200(MEXICO) 2011- ISUZU Vehicle Trucks
11413 FORWARD1500(MEXICO) 2011- ISUZU Vehicle Trucks
11414 FRR-R S-CAB EURO5 2011- ISUZU Vehicle Trucks
11415 FRR(AUST)EU4 EXC.SPA 2008- ISUZU Vehicle Trucks
11416 FRR(AUST)EURO4 SPACE 2008- ISUZU Vehicle Trucks
11417 FSR(MIDEAST) 2008- ISUZU Vehicle Trucks
11418 FSR(AUST)EU4 EXC.SPA 2008- ISUZU Vehicle Trucks
11419 FSS(AUST)EURO4 2008- ISUZU Vehicle Trucks
11420 FTR(AUST)EURO4 2008- ISUZU Vehicle Trucks
11421 FTS(AUST)EURO4 2008- ISUZU Vehicle Trucks
11422 FTS(MIDEAST) 2008- ISUZU Vehicle Trucks
11423 FVM(AUST)EURO4 2008- ISUZU Vehicle Trucks
11424 FVR(MIDEAST) 2008- ISUZU Vehicle Trucks
11425 FVR/GVR(AUST)EURO4 2008- ISUZU Vehicle Trucks
11426 FVZ(AUST)EURO4 2008- ISUZU Vehicle Trucks
11427 FXR/GXR(AUST)JNLT05 2008-2012 ISUZU Vehicle Trucks
11429 FXZ(AUST)JNLT05 2008-2012 ISUZU Vehicle Trucks
11430 FTR(INDONESIA)4HK1 2011- ISUZU Vehicle Trucks
11433 FSS(BANGLADESH) 2000- ISUZU Vehicle Trucks
11434 FTS(PAKISTAN)S-TIRE 2010- ISUZU Vehicle Trucks
11438 FTS(PAKISTAN)D-TIRE 2010- ISUZU Vehicle Trucks
11439 FVR(IRAN) 2011- ISUZU Vehicle Trucks
11440 FRR-L SPACE EU4 DOC 2011- ISUZU Vehicle Trucks
11462 GXZ CNG(THAI)EURO3 2012- ISUZU Vehicle Trucks
11463 FVR(MALAYSIA) 2012- ISUZU Vehicle Trucks
11466 FVZ(LHD)W/DOC EURO4 2012- ISUZU Vehicle Trucks
11475 FRR-L EURO5 EXC.SPAC 2013- ISUZU Vehicle Trucks
11476 FRR(THAI)EURO3 2013- ISUZU Vehicle Trucks
11488 FTR(THAI)EURO3 2013-2013 ISUZU Vehicle Trucks
11491 FVM(THAI)EURO3 2013- ISUZU Vehicle Trucks
11492 FVZ(THAI)EURO3 2013- ISUZU Vehicle Trucks
11493 FXZ/GXZ(THAI)EURO3 2013- ISUZU Vehicle Trucks
11496 FVR(LHD) EURO5 2013- ISUZU Vehicle Trucks
11498 GVR(THAI)EURO3 2013- ISUZU Vehicle Trucks
11499 FYH(AUST)EURO5 2013- ISUZU Vehicle Trucks
11500 FYH(THAILAND)EURO3 2013- ISUZU Vehicle Trucks
11501 CYZ(LHD)EURO5 2013- ISUZU Vehicle Trucks
11502 EXR(RHD) EURO2 2013- ISUZU Vehicle Trucks
11504 FRR-L EURO2 EXC.SPAC 2013- ISUZU Vehicle Trucks
11505 FRR(LHD) SPACECAB 2013- ISUZU Vehicle Trucks



11506 FRR-R EURO2 EXC.SPAC 2013- ISUZU Vehicle Trucks
11507 FRR-R S-CAB EURO2/4 2013- ISUZU Vehicle Trucks
11508 FSR(LHD) 2013- ISUZU Vehicle Trucks
11509 FSR-R EU2/4EXC.SPACE 2013- ISUZU Vehicle Trucks
11510 FSS(RHD)EURO2 2013- ISUZU Vehicle Trucks
11511 FSS(LHD) 2013- ISUZU Vehicle Trucks
11512 FTR(LHD) 2013- ISUZU Vehicle Trucks
11513 FTR-RHD EURO2 2013- ISUZU Vehicle Trucks
11514 FTS(RHD)EURO2 2013- ISUZU Vehicle Trucks
11515 FTS(LHD) 2013- ISUZU Vehicle Trucks
11516 FVM(RHD) 2013- ISUZU Vehicle Trucks
11517 FVM(LHD) 2013- ISUZU Vehicle Trucks
11518 FVR/GVR-L EURO2/3/4 2013- ISUZU Vehicle Trucks
11519 FVR/GVR-RHD EURO2/4 2013- ISUZU Vehicle Trucks
11520 FVZ(RHD) 2013- ISUZU Vehicle Trucks
11521 FVZ(LHD) 2013- ISUZU Vehicle Trucks
11524 CYH(RHD) EURO2 2013- ISUZU Vehicle Trucks
11525 CYZ(CHINA) EURO4 2013- ISUZU Vehicle Trucks
11526 EXZ(RHD) EURO2 2013- ISUZU Vehicle Trucks
11527 FVR(MALAYSIA) 280PS 2013- ISUZU Vehicle Trucks
11528 GXR(RHD)EURO3 2013- ISUZU Vehicle Trucks
11529 GXR(RHD)EURO5 2013- ISUZU Vehicle Trucks
11530 FXZ/GXZ(RHD)EURO3 2013- ISUZU Vehicle Trucks
11533 CYH(LHD) EURO2 W/REF 2013- ISUZU Vehicle Trucks
11534 CYJ(RHD)EURO5 2013- ISUZU Vehicle Trucks
11535 CYZ(RHD) EURO2 2013- ISUZU Vehicle Trucks
11536 EXZ(LHD) EURO2 2013- ISUZU Vehicle Trucks
11537 CYZ(LHD)EURO2 2013- ISUZU Vehicle Trucks
11538 EXR(LHD) EURO2 2013- ISUZU Vehicle Trucks
11539 CYH(CHINA) EURO4 2013- ISUZU Vehicle Trucks
11540 FTR CNG(THAILAND) 2013- ISUZU Vehicle Trucks
11541 FVM CNG(THAILAND) 2013- ISUZU Vehicle Trucks
11542 FXZ/GXZ CNG(THAI)EU3 2013- ISUZU Vehicle Trucks
11543 GVR CNG(THAILAND) 2013- ISUZU Vehicle Trucks
11544 FVZ(MALAYSIA) 2013- ISUZU Vehicle Trucks
11545 FRR-LHD(EU)SPACE EU6 2014- ISUZU Vehicle Trucks
11546 FRR-R(EU)E6 EXC.SPAC 2014- ISUZU Vehicle Trucks
11547 FRR-RHD(EU)SPACE EU6 2014- ISUZU Vehicle Trucks
11548 FRR(AUST/NZ)E5 EXC.S 2014- ISUZU Vehicle Trucks
11549 FRR(AUST/NZ)E5 SPAC 2014- ISUZU Vehicle Trucks
11550 FSR(AUST/NZ)EURO5 2014- ISUZU Vehicle Trucks
11551 FRR-L EURO5 EXC.SPAC 2014- ISUZU Vehicle Trucks
11552 FRR-R EU5 EXC.SPACE 2014- ISUZU Vehicle Trucks
11553 FRR-R EU5 SPACE 2014- ISUZU Vehicle Trucks
11554 FSR-R EU5 EXC.SPACE 2014- ISUZU Vehicle Trucks
11555 FTR-RHD EURO5 2014- ISUZU Vehicle Trucks
11556 FVR-RHD EURO5 2014- ISUZU Vehicle Trucks
11560 FSR-RHD(EU)SPACE EU6 2014- ISUZU Vehicle Trucks
11561 FSR-LHD(EU)SPACE EU6 2014- ISUZU Vehicle Trucks
11563 FRR(INDONESIA) 2014- ISUZU Vehicle Trucks
11564 FTR(INDONESIA) 2014- ISUZU Vehicle Trucks
11565 FVM(INDONESIA)6HK1 2014- ISUZU Vehicle Trucks



11566 FVR(INDONESIA) 2014- ISUZU Vehicle Trucks
11567 FVZ(INDONESIA) 2014- ISUZU Vehicle Trucks
11568 GXR(MALAYSIA)EURO3 2014- ISUZU Vehicle Trucks
11569 FXZ/GXZ(MALAYSIA)EU3 2014- ISUZU Vehicle Trucks
11570 FVZ(MIDDLE EAST)EU2 2014- ISUZU Vehicle Trucks
11574 FRR(THAI)EURO3 2014- ISUZU Vehicle Trucks
11575 FTR(THAI)EURO3 2014- ISUZU Vehicle Trucks
11576 FTR CNG(THAILAND) 2014- ISUZU Vehicle Trucks
11577 FVM(THAI)EURO3 2014- ISUZU Vehicle Trucks
11578 FVM CNG(THAILAND) 2014- ISUZU Vehicle Trucks
11579 FVZ(THAI)EURO3 2014- ISUZU Vehicle Trucks
11580 GVR(THAI)EURO3 2014- ISUZU Vehicle Trucks
11581 GVR CNG(THAILAND) 2014- ISUZU Vehicle Trucks
50693 NHR 1994-1998 ISUZU Vehicle Trucks
50694 NKR-RHD 1994-1998 ISUZU Vehicle Trucks
50695 NKR-LHD 1994-1998 ISUZU Vehicle Trucks
50696 NPR/NQR-RHD 1994-1998 ISUZU Vehicle Trucks
50697 NPR/NQR-LHD 1994-1998 ISUZU Vehicle Trucks
50701 NPS-RHD 1994- ISUZU Vehicle Trucks
50760 NHR/NKR TAIWAN 1997-2007 ISUZU Vehicle Trucks
50783 NPR(MALAYSIA) 1997- ISUZU Vehicle Trucks
50784 NKR(MALAYSIA) 1997- ISUZU Vehicle Trucks
50785 NHR(MALAYSIA) 1997- ISUZU Vehicle Trucks
50808 NHR 1999-2002 ISUZU Vehicle Trucks
50809 NKR-LHD 1999-2002 ISUZU Vehicle Trucks
50810 NKR(EUROPE)-LHD 1999-2002 ISUZU Vehicle Trucks
50812 NKR-RHD 1999-2002 ISUZU Vehicle Trucks
50813 NKR(EUROPE)-RHD 1999-2002 ISUZU Vehicle Trucks
50814 NKR(THAILAND) 1999-2002 ISUZU Vehicle Trucks
50815 NPR/NQR-LHD 1999-2002 ISUZU Vehicle Trucks
50816 NPR/NQR(EUROPE)-LHD 1999-2002 ISUZU Vehicle Trucks
50817 NPR/NQR-RHD 1999-2002 ISUZU Vehicle Trucks
50818 NPR/NQR(EUROPE)-RHD 1999-2002 ISUZU Vehicle Trucks
50819 NPR/NQR(THAILAND) 2000-2002 ISUZU Vehicle Trucks
50915 NP/NQ BUS LHDEXC.EU4 2001- ISUZU Vehicle Trucks
50916 NPR(BUS CHAS)RHD 2002- ISUZU Vehicle Trucks
50942 NHR 2003- ISUZU Vehicle Trucks
"50943 NKR55 66 69 71 77LHD 2003-" ISUZU Vehicle Trucks
50944 NKR(RHD)EXC.EURO4 2003- ISUZU Vehicle Trucks
50945 NKR(EUROPE)-LHD 2004- ISUZU Vehicle Trucks
50946 NKR(EUROPE)-RHD 2004- ISUZU Vehicle Trucks
50947 NPR/NQR LHDEXC.EURO4 2003- ISUZU Vehicle Trucks
50948 NPR/NQR RHDEXC.EURO4 2003- ISUZU Vehicle Trucks
50949 NPR/NQR(EUROPE)-LHD 2004- ISUZU Vehicle Trucks
50950 NPR/NQR(EUROPE)-RHD 2004- ISUZU Vehicle Trucks
50953 NKR(SOUTH AFRICA) 2003- ISUZU Vehicle Trucks
50954 NPR/NQR(SOUTHAFRICA) 2003-2006 ISUZU Vehicle Trucks
50970 NKR(THAILAND) 2003-2004 ISUZU Vehicle Trucks
50971 NPR/NQR(THAILAND) 2003-2004 ISUZU Vehicle Trucks
50980 NPR(IRAN) 2004- ISUZU Vehicle Trucks
51036 NPS-LHD 2005- ISUZU Vehicle Trucks
51038 NQR(IRAN) 2005- ISUZU Vehicle Trucks



51040 NKR(THAILAND) 2005- ISUZU Vehicle Trucks
51041 NPR/NQR(THAILAND) 2005- ISUZU Vehicle Trucks
51047 ELF400/450(MEXICO) 2006-2008 ISUZU Vehicle Trucks
51101 NHR EURO4 2007- ISUZU Vehicle Trucks
51102 NKR(RHD)EURO4 2007- ISUZU Vehicle Trucks
51103 NPR/NQR(LHD) EURO4 2007- ISUZU Vehicle Trucks
51104 NP/NQR BUS(LHD)EURO4 2007-2007 ISUZU Vehicle Trucks
51124 NPR/NQR(RHD) EURO4 2007- ISUZU Vehicle Trucks
51126 NKR(IRAN) 2006- ISUZU Vehicle Trucks
51127 NKR85(LHD) 2007- ISUZU Vehicle Trucks
51132 NQR BUS CHAS(THAI) 2007- ISUZU Vehicle Trucks
51136 NPS-RHD 2007- ISUZU Vehicle Trucks
51139 ELF300(MEXICO) 2007-2008 ISUZU Vehicle Trucks
51145 NHR 2008- ISUZU Vehicle Trucks
51146 NLR/NMR(SOUTHAFRICA) 2008- ISUZU Vehicle Trucks
"51147 NLR/NMR 55 85(LHD) 2008-2010" ISUZU Vehicle Trucks
51148 NLR/NMR(EU)-LHD EU4 2009- ISUZU Vehicle Trucks
"51149 NLR/NMR 55 85(RHD) 2008-2010" ISUZU Vehicle Trucks
51150 NLR/NMR(EU)-RHD EU4 2009- ISUZU Vehicle Trucks
51154 NN/NP/NQR-LHDEXC.EU1 2008-2010 ISUZU Vehicle Trucks
51155 NNR/NPR EU-L EXC.EU5 2009- ISUZU Vehicle Trucks
51156 NPR BUS(LHD) 2008-2010 ISUZU Vehicle Trucks
51157 NN/NP/NQR-R EXC.EU5 2008-2010 ISUZU Vehicle Trucks
51158 NNR/NPR EU-R EXC.EU5 2009- ISUZU Vehicle Trucks
51159 NPR(BUS CHAS)RHD 2008-2010 ISUZU Vehicle Trucks
51162 NPS-RHD 2008-2010 ISUZU Vehicle Trucks
51163 NPS-LHD 2008-2010 ISUZU Vehicle Trucks
51168 NLR/NMR(THAILAND) 2008- ISUZU Vehicle Trucks
51169 NPR/NQR(THAILAND) 2008- ISUZU Vehicle Trucks
51172 NPR/NQR(SOUTHAFRICA) 2008- ISUZU Vehicle Trucks
51173 NPS(SOUTH AFRICA) 2008- ISUZU Vehicle Trucks
51174 ELF400/500/600/BUS 2009- ISUZU Vehicle Trucks
51175 NLS(EUROPE)LHD 2009- ISUZU Vehicle Trucks
51176 NLS(EUROPE)RHD 2009- ISUZU Vehicle Trucks
51183 NMR71-LHD 2009- ISUZU Vehicle Trucks
51184 NMR71-RHD 2009- ISUZU Vehicle Trucks
51185 NPR/NQR(LHD) EURO1 2009- ISUZU Vehicle Trucks
51186 NPR BUS(LHD)EURO1 2009- ISUZU Vehicle Trucks
51187 NPR/NQR(RHD) EURO1 2009- ISUZU Vehicle Trucks
51188 NPR BUS(RHD)EURO1 2009- ISUZU Vehicle Trucks
51189 NPS(RHD)EURO1 2009- ISUZU Vehicle Trucks
51190 NPS(LHD)EURO1 2009- ISUZU Vehicle Trucks
51205 ELF200/300(MEXICO) 2009-2010 ISUZU Vehicle Trucks
51237 NNR/NPR(EU)-LHD EU5 2010- ISUZU Vehicle Trucks
51238 NPR BUS CHASSIS(LHD) 2013- ISUZU Vehicle Trucks
51239 NN/NP/NQR-RHD EURO5 2009- ISUZU Vehicle Trucks
51240 NNR/NPR EU-RHD EURO5 2010- ISUZU Vehicle Trucks
51241 NPR CNG(THAILAND) 2009- ISUZU Vehicle Trucks
51242 NMR CNG(THAILAND) 2009- ISUZU Vehicle Trucks
51244 NPR(LHD) EURO5 2009- ISUZU Vehicle Trucks
51245 NPR CNG-LHD 2010- ISUZU Vehicle Trucks
51248 NLR85(LHD) 2009- ISUZU Vehicle Trucks



51249 NLR/NMR(EU)-LHD EU5 2010- ISUZU Vehicle Trucks
51250 NMR85(RHD)EURO5 2009- ISUZU Vehicle Trucks
51251 NLR/NMR(EU)-RHD EU5 2010- ISUZU Vehicle Trucks
51258 NLS-RHD 2009- ISUZU Vehicle Trucks
51259 NPR CNG-RHD 2009- ISUZU Vehicle Trucks
51264 NLR CNG-RHD 2009- ISUZU Vehicle Trucks
51266 NP/NQR(LHD)EU4 W/DOC 2010- ISUZU Vehicle Trucks
51267 NN/NP/NQR(RHD)EURO4 2012- ISUZU Vehicle Trucks
51272 NPS EURO5 AUST/NZ 2011- ISUZU Vehicle Trucks
51275 NL/NMR85 EU5 AUST/NZ 2011- ISUZU Vehicle Trucks
51276 NN/NP/NQR EU5 AUS/NZ 2011- ISUZU Vehicle Trucks
51278 NKR MIDDLE EAST 2003-2008 ISUZU Vehicle Trucks
51279 NKR AUSTRALIA 2003-2006 ISUZU Vehicle Trucks
51280 NKR INDONESIA 2003-2008 ISUZU Vehicle Trucks
"51282 NLR/NMR 55 85(LHD) 2011-" ISUZU Vehicle Trucks
51283 NMR(MIDDLE EAST) 2011- ISUZU Vehicle Trucks
"51284 NLR/NMR55 71 85(RHD) 2011-" ISUZU Vehicle Trucks
51287 ELF200/300(MEXICO) 2011- ISUZU Vehicle Trucks
51291 NPS(SOUTH AFRICA) 2013- ISUZU Vehicle Trucks
51292 NPR BUS CHASSIS(LHD) 2011- ISUZU Vehicle Trucks
51293 NNR/NPR/NQR(LHD) 2011- ISUZU Vehicle Trucks
51294 NQR INDONESIA 2012- ISUZU Vehicle Trucks
51295 NPR(BUS CHAS)RHD 2011- ISUZU Vehicle Trucks
51296 NPR/NQR-RHD 2011- ISUZU Vehicle Trucks
51297 NPR/NQR(MIDDLE EAST) 2011- ISUZU Vehicle Trucks
51300 NPR(IRAN) 2012- ISUZU Vehicle Trucks
51301 NPS-RHD 2011- ISUZU Vehicle Trucks
51302 NPS(LHD) 2011- ISUZU Vehicle Trucks
51352 QKR-LHD 2011- ISUZU Vehicle Trucks
51353 QKR-RHD 2011- ISUZU Vehicle Trucks
51354 NLR/NMR 85(LHD)EURO4 2011- ISUZU Vehicle Trucks
51355 NPR/NQR(MIDDLE EAST) 2008-2010 ISUZU Vehicle Trucks
51356 NPR/NQR(MIDDLE EAST) 2003-2007 ISUZU Vehicle Trucks
51376 QKR(MIDDLE EAST) 2011- ISUZU Vehicle Trucks
51381 NPR BUS CNG(LHD) 2011- ISUZU Vehicle Trucks
51382 NHR(INDONESIA) 2003-2005 ISUZU Vehicle Trucks
51383 NHR(MIDDLE EAST) 2003-2005 ISUZU Vehicle Trucks
51384 NMR 85(MIDDLE EAST) 2008- ISUZU Vehicle Trucks
51385 NMR 71(MIDDLE EAST) 2009-2010 ISUZU Vehicle Trucks
51386 NQR AIR BRAKE RHD 2012- ISUZU Vehicle Trucks
51387 NP/NQR AIR BRAKE LHD 2012- ISUZU Vehicle Trucks
51390 NQR A/BRAKE MIDEAST 2014- ISUZU Vehicle Trucks
51391 NQR BUS A/BRAKE RHD 2012- ISUZU Vehicle Trucks
51392 NQR BUS A/BRAKE LHD 2012- ISUZU Vehicle Trucks
51394 NLR 85(AUST) 2008-2008 ISUZU Vehicle Trucks
51395 NLR/NMR(INDONESIA) 2008- ISUZU Vehicle Trucks
51396 NPR(MIDDLE EAST) 2009-2009 ISUZU Vehicle Trucks
51397 NPR/NQR(AUST) 2003-2005 ISUZU Vehicle Trucks
51398 NNR/NPR/NQR(AUST) 2008- ISUZU Vehicle Trucks
51399 NQR(INDONESIA) 2008- ISUZU Vehicle Trucks
51402 NPS INDONESIA 2003-2007 ISUZU Vehicle Trucks
51403 NPS INDONESIA 2008- ISUZU Vehicle Trucks



51405 NHR(RHD)EURO4 W/DOC 2012- ISUZU Vehicle Trucks
51409 NPS(AUSTRALIA) 2003-2007 ISUZU Vehicle Trucks
51410 NPS(AUST) 2008-2008 ISUZU Vehicle Trucks
51418 NMR 85(RHD)EURO4 2012- ISUZU Vehicle Trucks
51422 QKR LHD 2012- ISUZU Vehicle Trucks
51423 QKR RHD 2012- ISUZU Vehicle Trucks
51429 NKR-LHD 2012- ISUZU Vehicle Trucks
51479 NLR/NMR(THAILAND) 2013- ISUZU Vehicle Trucks
"51481 NNR/NPR EU-L EU5B+ 6 2014-" ISUZU Vehicle Trucks
"51482 NNR/NPR EU-R EU5B+ 6 2014-" ISUZU Vehicle Trucks
51483 NPR/NQR(THAILAND) 2013- ISUZU Vehicle Trucks
51486 NLR/NMR(SOUTHAFRICA) 2013- ISUZU Vehicle Trucks
51487 NPR/NQR(SOUTHAFRICA) 2013- ISUZU Vehicle Trucks
51492 NPR BUS CHAS(THAI) 2013- ISUZU Vehicle Trucks
51495 NPR(GM EGYPT) 2011- ISUZU Vehicle Trucks
"51496 NL/NMR(EU)-L EU5B+ 6 2014-" ISUZU Vehicle Trucks
"51497 NL/NMR(EU)-R EU5B+ 6 2014-" ISUZU Vehicle Trucks
51500 NPS(MALAYSIA) 2013- ISUZU Vehicle Trucks
51501 NPR(MALAYSIA) 2013- ISUZU Vehicle Trucks
51502 NLR(MALAYSIA) 2014- ISUZU Vehicle Trucks

Isuzu Industrial Engine

10382 6BD1 1977-1992 ISUZU Engine Industrial engine
10383 6BD1T 1977-1992 ISUZU Engine Industrial engine
10392 6BB1 1977-1992 ISUZU Engine Industrial engine
10393 6BB1 1993-1997 ISUZU Engine Industrial engine
10394 8PA1 1980-1997 ISUZU Engine Industrial engine
10395 6SA1 1985-1996 ISUZU Engine Industrial engine
10397 E120 1971-1974 ISUZU Engine Industrial engine
10398 DA640 1975-1980 ISUZU Engine Industrial engine
10399 12PB1 1980-1994 ISUZU Engine industrial engine
10400 6QA1 1983-1993 ISUZU Engine Industrial engine
10401 E120 1975-1992 ISUZU Engine Industrial engine
10402 E120 1993-1994 ISUZU Engine Industrial engine
10766 6SD1 1988- ISUZU Engine Industrial engine
10767 6BD1 1993- ISUZU Engine Industrial engine
10769 6RB1 1983- ISUZU Engine Industrial engine
10770 10PB1 1979- ISUZU Engine Industrial engine
10822 6BD1(EXP) 1993- ISUZU Engine INDUSTRIAL ENGINE
10855 6HK1 2000- ISUZU Engine Industrial engine
10856 6WG1 2000- ISUZU Engine Industrial engine
10931 6BG1(N) 1985- ISUZU Engine Industrial engine
10932 6BG1(T) 1985- ISUZU Engine Industrial engine
11007 6HK1 TIER3/STAGE 3A 2005- ISUZU Engine Industrial engine
11008 6WG1 TIER3/STAGE 3A 2005- ISUZU Engine Industrial engine
11034 6UZ1 TIER3/STAGE 3A 2006- ISUZU Engine Industrial engine
11299 6HK1 TIER4/STAGE 3B 2010- ISUZU Engine INDUSTRIAL ENGINE
11300 6WG1 TIER4/STAGE 3B 2010- ISUZU Engine INDUSTRIAL ENGINE
11301 6UZ1 TIER4/STAGE 3B 2010- ISUZU Engine INDUSTRIAL ENGINE
50319 4JA1/4JB1/4JC1 1984-1994 ISUZU Engine Industrial engine
50320 4BD1 1980-1993 ISUZU Engine Industrial engine
50321 C240 1981-1992 ISUZU Engine Industrial engine



50326 C240 1976-1980 ISUZU Engine Industrial engine
50329 3KR1 1994-1997 ISUZU Engine Industrial engine
50330 3KA1/3KB1/3KC1 1985-1992 ISUZU Engine Industrial engine
50331 3KA1/3KB1/3KC1 1993-1997 ISUZU Engine Industrial engine
50332 4FE1 1985-1995 ISUZU Engine Industrial engine
50334 3KC2 1989-1996 ISUZU Engine Industrial engine
50335 3KR2 1989-1995 ISUZU Engine Industrial engine
50336 4BC2 1981-1993 ISUZU Engine Industrial engine
50337 4BC2 1993-1994 ISUZU Engine Industrial engine
50338 4FB1/4FC1 1981-1992 ISUZU Engine Industrial engine
50339 4FB1/4FC1 1993-1995 ISUZU Engine Industrial engine
50343 3KR1 1984-1993 ISUZU Engine Industrial engine
50345 2KC1 1993-1997 ISUZU Engine industrial engine
50346 3KA1/3KB1/3KC1 1983-1984 ISUZU Engine Industrial engine
50347 3AA1/3AB1 1972-1975 ISUZU Engine Industrial engine
50348 3AA1/3AB1/3AD1 1976-1991 ISUZU Engine Industrial engine
50349 4JD1/4JE1/4JF1 1987-1994 ISUZU Engine Industrial engine
50350 3AE1/3AF1 1979-1989 ISUZU Engine industrial engine
50351 3AB1 1992-1994 ISUZU Engine Industrial engine
50791 4BG1 1989- ISUZU Engine Industrial engine
50792 3LA1/3LB1 1991- ISUZU Engine Industrial engine
50793 3LD1/3LD2 1992- ISUZU Engine Industrial engine
50794 4BD1 1994- ISUZU Engine Industrial engine
50795 4JA1/4JC1 1995- ISUZU Engine Industrial engine
50796 4JB1 1995- ISUZU Engine Industrial engine
50797 4JG1/4JG2 1993- ISUZU Engine Industrial engine
50798 4LB1/4LC1/4LE1/4LE2 1993- ISUZU Engine Industrial engine
50799 C240 1993- ISUZU Engine Industrial engine
50844 3YA1/3YB1/3YC1/3YE1 1995- ISUZU Engine Industrial engine
50845 2YA1 1991- ISUZU Engine industrial engine
50872 4BD1(EXP) 1993- ISUZU Engine INDUSTRIAL ENGINE
50873 C240(EXP) 1993- ISUZU Engine INDUSTRIAL ENGINE
50874 4BE1 1993- ISUZU Engine INDUSTRIAL ENGINE
50875 4BG1-BCVP 1993- ISUZU Engine INDUSTRIAL ENGINE
50974 3CA1/3CB1/3CD1/3CE1 2003- ISUZU Engine Industrial engine
51043 4HK1 TIER3/STAGE 3A 2005- ISUZU Engine Industrial engine
51045 4CG1/4CG2 2005- ISUZU Engine INDUSTRIAL ENGINE
51046 2CA1 2005- ISUZU Engine INDUSTRIAL ENGINE
51052 4BA1 1977-1991 ISUZU Engine Industrial engine
51053 C330 1977-1980 ISUZU Engine Industrial engine
51054 4FA1 1980-1991 ISUZU Engine Industrial engine
51055 2AA1/2AB1 1977-1991 ISUZU Engine Industrial engine
51056 2KA1/2KB1/2KC1 1983-1993 ISUZU Engine Industrial engine
51106 4JJ1 TIER3/STAGE 3A 2006- ISUZU Engine Industrial engine
51165 4LE1/4LE2 TIER4 2007- ISUZU Engine Industrial engine
51274 4HK1 TIER4/STAGE 3B 2010- ISUZU Engine INDUSTRIAL ENGINE
51400 4JJ1 TIER4/STAGE 3B 2011- ISUZU Engine INDUSTRIAL ENGINE
51417 4JG1 CHINA 2012- ISUZU Engine INDUSTRIAL ENGINE
51427 4LE2 TIER4 2012- ISUZU Engine INDUSTRIAL ENGINE

Isuzu Marine Engine

10386 UM6BG1 1985-1992 ISUZU Engine Marine engine



10387 UM6RB1 1986-1993 ISUZU Engine marine engine
10388 UM6BB1/UM6BD1 1973-1992 ISUZU Engine Marine engine
10797 UM6HE1 1995- ISUZU Engine Marine engine
10798 UM6WG1 1999- ISUZU Engine Marine engine
10799 UM6BD1 1992- ISUZU Engine Marine engine
10800 UM6BG1 1993- ISUZU Engine Marine engine
10801 UM6RB1 1994- ISUZU Engine Marine engine
10802 UM6SD1 1988- ISUZU Engine Marine engine
10803 UM12PD1 1991- ISUZU Engine Marine engine
11014 UM6WF1 2005- ISUZU Engine Marine engine
11016 UM6QA1 1982-1990 ISUZU Engine Marine engine
11017 UM6SA1 1983-1992 ISUZU Engine Marine engine
11018 UM8PB1 1982-1990 ISUZU Engine Marine engine
11019 UM12PB1 1993-1993 ISUZU Engine Marine engine
11089 UM6HK1 2007- ISUZU Engine Marine engine
11119 UM6HK1(COMMON RAIL) 2007- ISUZU Engine Marine engine
11191 UM6WG1(COMMON RAIL) 2008- ISUZU Engine Marine engine
50323 UM4BD1 1971-1992 ISUZU Engine Marine engine
50327 UMC240 1971-1992 ISUZU Engine Marine engine
50846 UM3YA1/UM3YC1/UM3YD1 1994- ISUZU Engine marine engine
50847 UM4LC1 1995- ISUZU Engine Marine engine
50850 UM3KC1 1985- ISUZU Engine Marine engine
50851 UM4BD1 1993- ISUZU Engine Marine engine
50852 UM4BG1 1989- ISUZU Engine Marine engine
50853 UM4JA1/UM4JB1 1985- ISUZU Engine Marine engine
50854 UMC240 1993- ISUZU Engine Marine engine
50855 UM4JG1 1997- ISUZU Engine Marine engine
51057 UM2AB1 1971-1991 ISUZU Engine Marine engine
51058 UM2KC1 1988-1994 ISUZU Engine Marine engine
51059 UM3AB1 1971-1991 ISUZU Engine Marine engine
51060 UM4BA1 1978-1989 ISUZU Engine Marine engine
51061 UM4BB1 1971-1990 ISUZU Engine Marine engine
51062 UM4BC2 1982-1991 ISUZU Engine Marine engine

Isuzu Compo

11211 LR COMPOPARTS TURKEY 2009- ISUZU Vehicle Compo
11461 6HK1 COMPO(MALAYSIA) 2012- ISUZU Vehicle Compo

Isuzu Indonesia

FRR ISUZU Local Parts Information For Indonesia
FTR ISUZU Local Parts Information For Indonesia
FVM ISUZU Local Parts Information For Indonesia
FVR ISUZU Local Parts Information For Indonesia
FVZ ISUZU Local Parts Information For Indonesia

<http://www.autocatalogues.com>

<http://www.autocatalogues.com>

